

RELIEF E uropa

44719 ASSIETTE DE PRESENTATION EUROPA Ø 31 cm
Display plate Ø 12,2" / Teller flach / Plato presentacion

43006 ASSIETTE PL 2 EUROPA Ø 27 cm
*Dinner plate Ø 10,6" / Teller flach / Plato llano**

42972 ASSIETTE PL 3 EUROPA Ø 24 cm
*Dinner plate Ø 9,5" / Teller flach Ø / Plato llano**

42997 ASSIETTE PL 6 EUROPA Ø 20,5 cm
*Dessert Plate Ø 8,1" / Teller flach / Plato llano**

43547 ASSIETTE PL 9 EUROPA Ø 15 cm
*Dessert Plate Ø 5,9" / Teller flach / Plato llano**

43004 ASSIETTE CREUSE N° 3 EUROPA Ø 21,5 cm
Soup plate Ø 8,5" / Teller tief / Plato llano

43550 TASSE DEJEUNER EMPILABLE EUROPA 26 cl
*Breakfast cup stackable 8,8 oz
 Frühstück Tasse Obere stapelbar
 Taza desayuno apilable*

43602 SOUCOUBE MIXTE EUROPA : thé, déjeuner, bol. Ø 16 cm
*Saucer: tea, soup, breakfast 6,3 oz
 Untertasse für Kaffee, Frühstück und Suppen.
 Platillo (Té desayuno, tazon)*

43542 TASSE THE EMPILABLE EUROPA 18 cl
*Tea cup stackable 6,1 oz
 Kaffee / Tee Tasse Obere stapelbar / Taza Té apilable*

43207 TASSE CAFE EMPILABLE EUROPA 9 cl
*Coffee cup stackable 3 oz
 Moka Tasse Obere stapelbar / Taza café apilable*

43784 SOUCOUBE CAFE EUROPA Ø 12,2 cm
*Coffee saucer Ø 4,8"
 Untertasse für Moka Tasse / Platillo café*

43718 CAFETIERE EUROPA 27 cl
Coffee pot 9,1 oz / Kaffeekanne / Cafetera

43717 CREMIER EUROPA 14 cl
Milk jug 4,7 oz / Milchkanne / Lechera

43709 BOL BOUILLON AVEC ANSES EUROPA 28 cl
*Soup bowl with handles 9,5 oz
 Suppentasse Obere / Tazon de caldo*



44719

43006

42972



42997

43547



43004



43550 / 43602

43542

43207 / 43784



43718

43717

43709

"L'association
 d'une aile
 large et de
 fines moulures
 croisées en
 relief"

