

FORME **P**risma

41002 ASSIETTE DE PRESENTATION PRISMA Ø 31 cm
 Display plate Ø 12,3" / Teller flach / Plato presentacion

41000 ASSIETTE PL 2 PRISMA Ø 28 cm
 Dinner Plate Ø 11" / Teller flach / Plato llano

40814 ASSIETTE PL 3 PRISMA Ø 26 cm
 Dinner Plate Ø 10,2" / Teller flach / Plato llano

40826 ASSIETTE PL 7 PRISMA Ø 21,5 cm
 Dinner plate Ø 8,5" / Teller flach / Plato llano

41008 ASSIETTE PL 9 PRISMA Ø 16,5 cm
 Dessert plate Ø 6,5" / Teller flach / Plato llano

40815 ASSIETTE CREUSE N° 3 PRISMA Ø 23,3 cm
 Soup plate Ø 9,2" / Teller tief / Plato hondo

40938 TASSE THE PRISMA 19 cl
 Tea cup 6,4 oz
 Kaffee / Tee Tasse Obere stapelbar / Taza Té

40950 SOUCOUCPE THE PRISMA Ø 15 cm
 Tea saucer Ø 5,9 oz
 Untertasse für Kaffee Tasse / Platillo Té

40936 TASSE CAFE PRISMA 9,5 cl
 Coffee cup 3,2 oz
 Moka Tasse Obere stapelbar / Taza café

40937 SOUCOUCPE CAFE PRISMA Ø 13 cm
 Coffee saucer Ø 5,1" /
 Untertasse für Moka Tasse / Platillo café



41002

41000

40814



40826

41008



40815



40938 / 40950



40936 / 40937

"La délicatesse et la douceur
 d'une forme octogonale"